SHOWERHEAD CARE

CLEAN FAST®

Heavy duty washroom cleaner

CLEAN FAST® is a highly efficient, multi surface, foaming bactericidal cleaner. The foam provides a longer contact time for a thorough, deep down clean. It quickly removes limescale, body fat and stubborn soil and leaves a long lasting, fresh tangerine fragrance. Passes EN 1276; kills range of bacteria, including Legionella pneumophila. Low environmental impact product.



SINGLE PRODUCT PROCEDURE FOR DESCALING & DISINFECTING SHOWERHEADS

TO CLEAN SHOWER HEADS:

Dismantle the shower head and place in a solution of **CLEAN FAST®** at a dilution rate of 1lt **CLEAN FAST®** to 4lt warm water.

Leave to soak for 30 minutes. Agitation with a nylon scrubbing brush may be necessary to remove heavy soil & limescale.

TO DISINFECT SHOWER HEADS:

To kill a range of bacteria including Legionella pneumophila.

Soak in a solution of **CLEAN FAST**[®] at a dilution rate of 1:50 warm water for a minimum of 5 minutes.

This procedure should be carried out every 3 months.





WASHROOM CLEANING

HOW TO USE

CLEANING & DISINFECTING:

Using the 750ml trigger spray bottle, spray onto the surface & wipe with a clean damp cloth.

For stubborn soiling & limescale, spray onto surface & leave for 30 seconds before agitating & wiping off.

To refill the foaming spray bottle from the 5 litre container, pour undiluted.

GENERAL CLEANING:

Dilute 1:50 parts warm water (100ml per 5lt bucket)

Damp mop floor or wipe surface with clean cloth.

To refill the foaming spray bottle, dilute upto 1:10 depending on application.

Not for use on enamel baths, marble or limestone. We would suggest using Evans Final Touch.







