# Low Foam-Light

## Neutral multi surface cleaner



Multi surface, low foaming neutral cleaner for use in combination scrubber dryer floor machines.

Ideal for use in supermarkets, shopping & leisure centres, airports & sports halls.



Unperfumed. Ideal for use wherever food & drinks are prepared or served.



Order Code: A176EEV2 Pack: 2 x 5 litre (10.60 kg) Pallet: 60 Packs

#### • Removes light to general soiling with one pass of the machine.

- Highly recommended for marble, terrazzo & polished floors.
- Can also be used for the general mopping of lightly soiled floors.
- Also suitable for vinyl, rubber, ceramic & sealed wood floors.

#### FOR USE WITH COMBINATION MACHINES:

Add to the solution tank at a concentration of 1 - 2% (10 - 20 ml per litre) depending on soiling.

#### **GENERAL CLEANING:**

Dilute 1:50 parts hot water (100 ml per 5 L / 3 x per 5 L) in a bucket. Mop or wipe surface.

#### **RELATED ITEMS:**

- Low Foam-Heavy Alkaline multi surface cleaner.
- Floor & Carpet Care Guide.



PRODUCT INFORMATION:

Appearance: Odour: pH - undiluted: Shelf life: Clear blue liquid Faint surfactant 7.5 3 years

COMPOSITION:

Contains a blend of nonionic surfactant, stabiliser, preservative & dye.

#### BIODEGRADABILITY:

All surfactants used in Evans Vanodine products comply with the current European Regulations concerning biodegradability & protection of the environment.

#### QUALITY ASSURANCE:

This product is manufactured in the U.K. by EVANS VANODINE INTERNATIONAL PLC under an ISO 9001 Quality Management System Cert. No. FM 09535 and an ISO 14001 Environmental Management System Cert. No. EMS 506072 registered by the British Standards Institution.

**REVISION DATE:** 01/06/16





### Evans Vanodine International plc

Brierley Road, Walton Summit, Preston, PR5 8AH, UK www.evansvanodine.co.uk | Tel: +44 (0)1772 322200 | Fax: +44 (0)1772 626000

