G.A.C.

General acid cleaner





Powerful, highly concentrated, heavy duty, acid based cleaner & descaler.

Ideal for removing mortar, plaster & rust from brickwork, stone & quarry tiles.





- Suitable for removing moss, algae & heavy soiling from patios & paving stones.
- Removes extremely heavy deposits of limescale & rust from porcelain toilets.

BRICKWORK, CONCRETE FLOORS & PATIOS:

Wet surface with cold water. Apply undiluted. Allow product a few minutes to react & agitate with brush. Hose down with clean water.

TOILET DESCALING:

Dilute 1:4 parts cold water.

Flush toilet, Force water around S bend with toilet brush. Apply cleaner & leave for 2 minutes, agitate with brush if necessary. Flush toilet.

Use undiluted for heavy limescale & stubborn stains.

NOT RECOMMENDED FOR USE ON STAINLESS STEEL & NON-FERROUS METALS.

RELATED ITEMS:

• Vanosolve - Maintenance cleaner.





Order Code: A076EEV2

Pack: 2 x 5 litre (11.6 kg) Pallet: 60 Packs

PRODUCT INFORMATION:

Appearance: Clear pale straw thin liquid

Odour: Hydrochloric acid

pH - undiluted: 0 Shelf life: 3 years

COMPOSITION:

Contains a blend of nonionic surfactants, hydrochloric acid & corrosion inhibitors.

BIODEGRADABILITY:

All surfactants used in Evans Vanodine products comply with the current European Regulations concerning biodegradability & protection of the environment.

QUALITY ASSURANCE:

This product is manufactured in the U.K. by EVANS VANODINE INTERNATIONAL PLC under an ISO 9001 Quality Management System Cert. No. FM 09535 and an ISO 14001 Environmental Management System Cert. No. EMS 506072 registered by the British Standards Institution.

REVISION DATE:

01/06/16





