Apeel

All purpose cleaner





Highly effective all purpose cleaner and degreaser. Leaves a clean, fresh, natural orange aroma.

Contains a natural ingredient



Low Environmental Impact



- Quickly removes ingrained dirt, heavy soil & grease.
- Neutral pH, making it suitable for use on a variety of surfaces including vinyl, rubber, ceramic, porcelain or paintwork.
- Highly recommended for removing body fat from shower areas & graffiti from certain surfaces.
- Available in a Ready to Use 750 ml trigger spray bottle.

GENERAL CLEANING:

Dilute upto 1:100 parts hot water (50 ml per 5 L / 2 x per 5 L). Mop or wipe surface.

REMOVAL OF GRAFFITI FROM PAINTWORK & CERTAIN OTHER SURFACES:

Dilute 50-50 with hot water. Apply to surface, leave for a few minutes, agitate & wipe clean.

RELATED ITEMS:

- Versatile Hard surface cleaner.
- High Class[™] Neutral hard surface cleaner.
- · Apeel RTU All purpose cleaner.







PRODUCT INFORMATION:

Clear yellow liquid Appearance: Odour: Citrus

pH - undiluted: 8.0 Shelf life: 3 years

COMPOSITION:

Contains a blend of glycol ether, nonionic surfactant, anionic surfactant, citrus terpenes. preservative & dyes.

BIODEGRADABILITY:

All surfactants used in Evans Vanodine products comply with the current European Regulations concerning biodegradability & protection of the environment.

QUALITY ASSURANCE:

This product is manufactured in the U.K. by EVANS VANODINE INTERNATIONAL PLC under an ISO 9001 Quality Management System Cert. No. FM 09535 and an ISO 14001 Environmental Management System Cert. No. EMS 506072 registered by the British Standards Institution.

REVISION DATE:

01/06/16







