

Crusader Oxy Destainer

For industrial & professional use only



Powerful peroxide destainer, which provides a safe bleaching action. Will not damage fabric.

Removes wine, fruit juice, coffee, tea & other stains.

Supplied in a natural see-through container to allow a visual check on the volume.

- Maintains fabric whiteness & colour brightness.
- Thin liquid which is easy to dispense.
- For use in 'on premise' laundry installations in the hotel & healthcare industry.
- For best results use in conjunction with Evans CRUSADER LAUNDRY LIQUID.

LAUNDRY MACHINE:

Dispense at a ratio of 3 - 5 mls per kg of dry fabric.

Using a suitable dosing pump, add into the main wash of the laundry programme. The wash temperature should exceed 60°C to ensure optimum performance.

NOT TO BE USED FOR HAND WASHING.

FOR PROFESSIONAL USE ONLY

Acquisition, possession or use by the general public is restricted.

RELATED ITEMS:

- Crusader Laundry Liquid.
- Crusader Fabric Conditioner.
- Housekeeping Guide.



10l

Order Code: C011IEV

Pack: 10 litre (11.78 kg)

Pallet: 78 Packs

20l

Order Code: C011JEV

Pack: 20 litre (23.98 kg)

Pallet: 32 Packs

PRODUCT INFORMATION:

Appearance: Clear colourless liquid
Odour: Odourless
pH - undiluted: 2.0
Shelf life: 1 year

COMPOSITION:

Contains 35% hydrogen peroxide.

BIODEGRADABILITY:

All surfactants used in Evans Vanodine products comply with the current European Regulations concerning biodegradability & protection of the environment.

QUALITY ASSURANCE:

EVANS VANODINE INTERNATIONAL PLC operates under an ISO 9001 Quality Management System Cert. No. FM 09535 and an ISO 14001 Environmental Management System Cert. No. EMS 506072 registered by the British Standards Institution.

REVISION DATE:

27/02/17



Evans Vanodine International plc

Brierley Road, Walton Summit, Preston, PR5 8AH, UK

www.evansvanodine.co.uk | Tel: +44 (0)1772 322200 | Fax: +44 (0)1772 626000



ISO 9001
Quality Management

ISO 14001
Environmental Management

