Epic Power[™]

Toilet & washroom cleaner descaler



Powerful, multi surface sulphamic acid based toilet cleaner. Provides a quick & effective cleaning action.

Thickened so it clings to vertical surfaces, allowing longer contact for better cleaning.



Low Environmental Impact www.evansgreentick.com.



Order Code: A174AEV Pack: 6 x 1 litre (6.86 kg) Pallet: 84 Packs

Rapidly removes limescale, body fat, soap scum & general soiling from toilets, urinals, sinks, showers & washroom fittings.

- Leaves a clean refreshing fragrance.
- Produces excellent results in soft, medium & hard water conditions.
- Suitable for use on a variety of surfaces including porcelain, stainless steel, chrome, ceramic & quarry tiles.
- Packed in a 1 litre angled neck bottle with finger grips & tamper proof cap.

TOILETS & URINALS:

Flush toilet or urinal. Force water around S bend with toilet brush. Apply undiluted & leave for 2 minutes, agitate with brush if necessary. Flush with clean water. **SANITARY WARE:**

Apply undiluted, wipe with a damp cloth. Rinse with clean water.

NOT SUITABLE FOR VITREOUS ENAMEL.

RELATED ITEMS:

- E-Phos[™] Perfumed cleaner sanitiser.
- Everfresh[™] Toilet & washroom cleaner.
- Toilet Cleaning Guide / Housekeeping Guide.





| Appearance: | Clear turquoise viscous |
|-----------------|-------------------------|
| | liquid |
| Odour: | Aqua |
| pH - undiluted: | 1.3 |
| Shelf life: | 3 years |

COMPOSITION:

Contains a blend of sulphamic acid, nonionic surfactant, viscosity builder, perfume & dye.

BIODEGRADABILITY:

All surfactants used in Evans Vanodine products comply with the current European Regulations concerning biodegradability & protection of the environment.

QUALITY ASSURANCE:

This product is manufactured in the U.K. by EVANS VANODINE INTERNATIONAL PLC under an ISO 9001 Quality Management System Cert. No. FM 09535 and an ISO 14001 Environmental Management System Cert. No. EMS 506072 registered by the British Standards Institution.

REVISION DATE: 01/06/16





Evans Vanodine International plc

Brierley Road, Walton Summit, Preston, PR5 8AH, UK www.evansvanodine.co.uk | Tel: +44 (0)1772 322200 | Fax: +44 (0)1772 626000

