H.S.C.

Hard surface cleaner





A blend of specialised surfactants to provide an efficient, quick acting general purpose cleaner.

Rapidly removes dirt & ingrained soiling from all washable surfaces.



Leaves a clean fresh lemon fragrance.



- Ideal for damp mopping or using in a spray on-wipe off cleaning system.
- Suitable for use on a number of surfaces including vinyl, rubber, concrete, laminate, ceramic, glass & painted surfaces.
- · Approved for POLYFLOR flooring.

GENERAL CLEANING:

Dilute 1:50 parts hot water (100 ml per 5 L / 3 x per 5 L) in a bucket. Mop or wipe surface.

HEAVY SOILING:

Dilute 1:25 parts hot water (200 ml per 5 L / 6 x per 5 L) in a bucket. Mop or wipe surface.

SPRAY ON - WIPE OFF:

Dilute 1:50 parts cold water (10 ml per 500 ml) in a hand spray bottle. Spray onto surface & wipe clean with a damp cloth.

RELATED ITEMS:

- Mystrol™ Concentrated all purpose cleaner.
- High Class[™] Neutral hard surface cleaner.







Order Code: A035EEV2

Pack: 2 x 5 litre (10.63 kg) Pallet: 60 Packs

PRODUCT INFORMATION:

Appearance: Clear yellow liquid Odour: Citrus

pH - undiluted: 10.6 Shelf life: 3 years

COMPOSITION:

Contains a blend of alkanolamine, sequestering agents, amphoteric surfactant, nonionic surfactant, perfume & dye.

${\tt BIODEGRADABILITY:}$

All surfactants used in Evans Vanodine products comply with the current European Regulations concerning biodegradability & protection of the environment.

QUALITY ASSURANCE:

This product is manufactured in the U.K. by EVANS VANODINE INTERNATIONAL PLC under an ISO 9001 Quality Management System Cert. No. FM 09535 and an ISO 14001 Environmental Management System Cert. No. EMS 506072 registered by the British Standards Institution.

REVISION DATE:

01/06/16









