# Safe Zone™


## Disinfectant cleaner





Bactericidal disinfectant cleaner for treating hard surfaces & soft furnishings contaminated with potentially infectious soiling.

Passes EN 1276 at a dilution of 1:25 under dirty conditions with a 30 second contact time.







- Helps to prevent cross contamination.
- Safe for use on carpets & all washable hard surfaces.
- Concentrated unperfumed formulation.
- Ideal for use in healthcare establishments or wherever there is a risk of infection.
- A microbiology profile available upon request.
- Available in a Ready to Use formulation supplied in 750 ml trigger spray bottles.
- Approved for POLYFLOR flooring.

## **DISINFECTING & CLEANING HARD SURFACES:**

Dilute 1:25 parts hot water (200 ml per  $5 L / 7 \times 10^{-5}$  per 5 L) in a bucket. Mop or wipe surface. Allow to air dry.

## TREATING & DISINFECTING CONTAMINATED AREAS & CARPETS:

Dilute 1:25 parts hot water (200 ml per 5 L / 7 x per 5 L) in a bucket. Wear disposable gloves. Remove any soiling & dispose of safely. Wipe or spray contaminated area & leave for 5 minutes. Apply further amount & gently agitate carpet with a soft nylon scrubbing brush. Blot carpet dry with paper towels & dispose of safely.

USE DISINFECTANTS SAFELY.
ALWAYS READ THE LABEL AND PRODUCT INFORMATION BEFORE USE.

## **RELATED ITEMS:**

- Safe Zone™ RTU Disinfectant cleaner.
- Protect<sup>™</sup> Disinfectant cleaner.





## Order Code: A024EEV2

Pack: 2 x 5 litres (10.65 kg) Pallet: 60 packs

## PRODUCT INFORMATION:

Appearance: Clear colourless liquid
Odour: Slight surfactant odour

pH - undiluted: 12.5 Shelf life: 3 years

## COMPOSITION:

Contains a blend of quaternary ammonium compound, sequestering agent & nonionic surfactant.

### BIODEGRADABILITY:

All surfactants used in Evans Vanodine products comply with the current European Regulations concerning biodegradability & protection of the environment.

### QUALITY ASSURANCE:

This product is manufactured in the U.K. by EVANS VANODINE INTERNATIONAL PLC under an ISO 9001 Quality Management System Cert. No. FM 09535 and an ISO 14001 Environmental Management System Cert. No. EMS 506072 registered by the British Standards Institution.

REVISION DATE:

01/06/16







