Sure Strip™

Floor polish stripper





Heavy duty, emulsion floor polish remover.

Concentrated to provide a quick effective action.

Strips all types of emulsion polish in conjunction with a floor machine & stripping pad.

Efficiently removes stubborn & resistant polish films.



- Removes polish film from a variety of surfaces including vinyl, rubber, linoleum, marble, terrazzo & sealed surfaces.
- Highly recommended for use a hard surface cleaner for removing heavy soil & grease.
- Approved for POLYFLOR flooring.

POLISH STRIPPING:

Dilute 1:20 parts warm water (250 ml per 5 L / 8 x $^{\bullet}$ per 5 L). For heavy polish build up dilute 500 ml per 5 L.

Mop solution generously onto section of floor, leave for 5 minutes.

Do not allow solution to dry out.

Machine scrub with stripping pad.

Remove slurry & rinse with cold water.

Neutralise floor by adding 1 part acetic acid (vinegar) to 300 parts water & damp mop the surface. Allow to air dry.

HEAVY DUTY CLEANING:

Dilute 1:50 parts warm water (100 ml per 5 L / 3 x per 5 L) Mop or wipe the surface.

RELATED ITEMS:

- Easy Strip[™] Fast acting floor polish stripper.
- Floor & Carpet Care Guide / Wallchart.
- DVD Training support films.









Order Code: A047EEV2

Pack: 2 x 5 litre (11.77 kg) Pallet: 60 Packs

PRODUCT INFORMATION:

Appearance: Clear dark red liquid
Odour: Characteristic
pH - undiluted: 13.4
Shelf life: 3 years

COMPOSITION:

Contains an aqueous solution of anionic surfactant, nonionic surfactant, solubiliser, sodium metasilicate, sequestering agent, solvent & dye.

BIODEGRADABILITY:

All surfactants used in Evans Vanodine products comply with the current European Regulations concerning biodegradability & protection of the environment.

QUALITY ASSURANCE:

This product is manufactured in the U.K. by EVANS VANODINE INTERNATIONAL PLC under an ISO 9001 Quality Management System Cert. No. FM 09535 and an ISO 14001 Environmental Management System Cert. No. EMS 506072 registered by the British Standards Institution.

REVISION DATE:

01/06/16





