

Crusader Alkali Booster

For industrial & professional use only



High active liquid formulation which can be automatically dosed into the washing machine.

Raises the alkalinity & pH of the wash solution to prevent the greying of linen.

Supplied in a natural see-through container to allow a visual check on the volume.

- Will assist the release of heavy soil from cotton & polyester cotton fabrics.
- Ideal for use in 'on premise' laundry installations in the hotel & healthcare industry.
- For best results use in conjunction with Evans CRUSADER LAUNDRY LIQUID.

LAUNDRY MACHINE:

For heavily soiled fabrics in 'on premise' laundry applications it should be dosed during the main wash phase of the wash programme in conjunction with Crusader Laundry Liquid at 6 - 12 ml per kilo of dry fabric.

It should be used only on linen, cotton & polyester cotton fabric.

NOT TO BE USED FOR HAND WASHING.

RELATED ITEMS:

- Crusader Fabric Conditioner.
- Crusader Laundry Liquid.



10l

Order Code: A144IEV

Pack: 10 litre (11.72 kg)

Pallet: 78 Packs

PRODUCT INFORMATION:

Appearance: Clear yellow liquid
Odour: No distinctive odour
pH - undiluted: 13.6
Shelf life: 3 years

COMPOSITION:

Contains a blend of sodium hydroxide & polymeric sequestrants.

BIODEGRADABILITY:

All surfactants used in Evans Vanodine products comply with the current European Regulations concerning biodegradability & protection of the environment.

QUALITY ASSURANCE:

EVANS VANODINE INTERNATIONAL PLC operates under an ISO 9001 Quality Management System Cert. No. FM 09535 and an ISO 14001 Environmental Management System Cert. No. EMS 506072 registered by the British Standards Institution.

REVISION DATE:

01/06/16



Evans Vanodine International plc

Brierley Road, Walton Summit, Preston, PR5 8AH, UK

www.evansvanodine.co.uk | Tel: +44 (0)1772 322200 | Fax: +44 (0)1772 626000



ISO
9001
Quality
Management

ISO
14001
Environmental
Management



2015