# **Trident**

## Sanitising powder



The blend of detergent & chlorine releasing agents make it suitable for a variety of applications in catering, housekeeping, leisure, healthcare & the dairy industry.

Cleans & disinfects washable hard surfaces & equipment in one operation.



Provides in excess of 10,000 ppm available chlorine. for use in high risk areas.



- Ideal wherever food is prepared, handled or served.
- Highly recommended for sanitising vending machines, refrigerators & for soaking cloths & mops.
- Removes tannin from crockery & mould & mildew from grout.
- Formulated to be used neat directly from the 500 g shaker pack or dissolved in water to solve a variety of tasks.

Food preparation surfaces & contaminated areas.	Sprinkle powder onto damp cloth or sponge & wipe surface until clean. Rinse with clean water & allow to air dry.	Available chlorine: In excess of 10,000 ppm
Kitchen & dairy equipment. Floors & walls.	Prepare a 4% solution (40 g per litre of warm water). Immerse washable equipment, Alternatively, wipe solution onto equipment & rinse with clean water. Allow to air dry.	Available chlorine: 1,000 ppm
Vending machines.	Prepare a 1% solution (10 g per litre warm water). Immerse removable parts in solution. Alternatively, wipe solution onto machine parts & rinse woth clean water. Allow to air dry.	Available chlorine: 250 ppm
Tannin removal & cloths.	Prepare a 1% solution (10 g per litre warm water). Immerse crockery or cloths for up to 30 minutes & rinse thoroughly with clean water. Allow to air dry.	Available chlorine: 250 ppm
Hand cleaning of bulk milk tanks.	Rinse tank with clean cold water. Sprinkle powder onto wet tank surfaces working into a paste with a soft tank brush. Brush paste over all surfaces, paying attention to paddle, bridge, underside of lids & outlet. Leave for 5 minutes & then rinse with clean cold water.	Available chlorine: In excess of 10,000 ppm



### Order Code: C010EV

Pack: 5 kilo bucket (5.27 kg) Pallet: 100 packs



#### Order Code: C010FEV

Pack: 12 x 500 g (6.75 kg) Pallet: 62 Packs



Appearance: Blue powder
Odour: Faint chlorine
pH - undiluted: 10.5 - 11.5
Shelf life: 3 years

#### COMPOSITION:

Contains a blend of sodium carbonate, sodium sichloroisocyanurate, anionic surfactant, phosphates & dye.

#### BIODEGRADABILITY:

All surfactants used in Evans Vanodine products comply with the current European Regulations concerning biodegradability & protection of the environment.

#### QUALITY ASSURANCE:

EVANS VANODINE INTERNATIONAL PLC operates under an ISO 9001 Quality Management System Cert. No. FM 09535 and an ISO 14001 Environmental Management System Cert. No. EMS 506072 registered by the British Standards Institution

**REVISION DATE:** 

01/06/16







