

## Heavy-duty cleaner degreaser



Powerful, high active multi purpose, heavy duty detergent for those really difficult cleaning tasks. Specially developed for a wide range of applications in kitchens & food processing areas.

Concentrate product.  
Very economical in use.

Low Environmental Impact -  
[www.evansgreentick.com](http://www.evansgreentick.com)




- Unperfumed. Ideal wherever food is handled, served or prepared.
- Easily removes fat, grease, oil & ingrained soiling.
- For use on a variety of washable surfaces including cooker hoods, deep fat fryers, ovens, floors & walls.
- Also suitable for removing heavy soil in engineering workshops & general industry.
- Suitable in all water conditions.
- Available in a Ready to Use formulation supplied in 750ml trigger spray bottles.
- Approved for ALTRO & POLYFLOR flooring.

### GENERAL CLEANING:


Dilute 1:250 parts hot water (20 ml per 5 L / 1 x  per 5 L). Mop, wipe or spray surface.

### HEAVY SOILING & GREASE:


Dilute 1:50 parts hot water (100 ml per 5 L / 3 x  per 5 L). Mop, wipe or spray surface.

### FOR CLEANING DEEP FAT FRYERS:

Switch off appliance, drain out oil & remove all deposits.

Dilute 1:25 (400 ml per 10 L / 13 x  per 10 L) cold water in fryer. Submerge basket & utensils in solution & soak overnight. Rinse with clean water & allow to air dry.

### TO RE-FILL THE LIFT RTU TRIGGER SPRAY BOTTLE:

Dilute 30 ml per 750 ml (1 x  per 750 ml) cold water.

### RELATED ITEMS:

- Est-eem® - Cleaner sanitiser.
- Q'det™ - Superior unperfumed washing up liquid.
- Kitchen Hygiene Guide / Wallchart.
- Kitchen Safety Signs.



5l

**Order Code: A054EEV2**

Pack: 2 x 5 litre (11.41 kg)

Pallet: 60 Packs

### PRODUCT INFORMATION:

Appearance: Clear pale straw liquid  
 Odour: Characteristic  
 pH - undiluted: 13.4  
 Shelf life: 3 years

### COMPOSITION:

Contains a blend of sodium metasilicate, anionic & nonionic surfactants, sequestering agent, solubiliser & glycol ether.

**BIODEGRADABILITY:** All surfactants used in Evans Vanodine products comply with the current European Regulations concerning biodegradability & protection of the environment.

**QUALITY ASSURANCE:** This product is manufactured in the U.K. by EVANS VANODINE INTERNATIONAL PLC under an ISO 9001 Quality Management System Cert. No. FM 09535 and an ISO 14001 Environmental Management System Cert. No. EMS 506072 registered by the British Standards Institution.

### REVISION DATE:

01/06/16



**Evans Vanodine International plc**

Brierley Road, Walton Summit, Preston, PR5 8AH, UK

[www.evansvanodine.co.uk](http://www.evansvanodine.co.uk) | Tel: +44 (0)1772 322200 | Fax: +44 (0)1772 626000



ISO  
9001  
Quality  
Management

ISO  
14001  
Environmental  
Management

